#### § 250.106

- (2) The inefficient, excessive, or improper use, or the unnecessary dissipation of reservoir energy:
- (3) The locating, spacing, drilling, equipping, operating, or producing of any oil, gas, or sulphur well(s) in a manner that causes or tends to cause a reduction in the quantity of oil, gas, or sulphur ultimately recoverable under prudent and proper operations or that causes or tends to cause unnecessary or excessive surface loss or destruction of oil or gas; or
  - (4) The inefficient storage of oil.

Welding means all activities connected with welding, including hot tapping and burning.

Wellbay is the area on a facility within the perimeter of the outermost wellheads

Well-completion operations mean the work conducted to establish production from a well after the production-casing string has been set, cemented, and pressure-tested.

Well-control fluid means drilling mud, completion fluid, or workover fluid as appropriate to the particular operation being conducted.

Western Gulf of Mexico means all OCS areas of the Gulf of Mexico except those the BOEM Director decides are adjacent to the State of Florida. The Western Gulf of Mexico is not the same as the Western Planning Area, an area established for OCS lease sales.

Workover operations mean the work conducted on wells after the initial well-completion operation for the purpose of maintaining or restoring the productivity of a well.

You means a lessee, the owner or holder of operating rights, a designated operator or agent of the lessee(s), a pipeline right-of-way holder, or a State lessee granted a right-of-use and easement.

[76 FR 64462, Oct. 18, 2011, as amended at 78 FR 20439, Apr. 5, 2013]

### PERFORMANCE STANDARDS

### § 250.106 What standards will the Director use to regulate lease operations?

The Director will regulate all operations under a lease, right-of-use and easement, or right-of-way to:

- (a) Promote orderly exploration, development, and production of mineral resources;
  - (b) Prevent injury or loss of life;
- (c) Prevent damage to or waste of any natural resource, property, or the environment: and
- (d) Cooperate and consult with affected States, local governments, other interested parties, and relevant Federal agencies.

# § 250.107 What must I do to protect health, safety, property, and the environment?

- (a) You must protect health, safety, property, and the environment by:
- (1) Performing all operations in a safe and workmanlike manner; and
- (2) Maintaining all equipment and work areas in a safe condition.
- (b) You must immediately control, remove, or otherwise correct any hazardous oil and gas accumulation or other health, safety, or fire hazard.
- (c) You must use the best available and safest technology (BAST) whenever practical on all exploration, development, and production operations. In general, we consider your compliance with BSEE regulations to be the use of BAST.
- (d) The Director may require additional measures to ensure the use of BAST:
- (1) To avoid the failure of equipment that would have a significant effect on safety, health, or the environment;
  - (2) If it is economically feasible; and
  - (3) If the benefits outweigh the costs.

## § 250.108 What requirements must I follow for cranes and other material-handling equipment?

- (a) All cranes installed on fixed platforms must be operated in accordance with American Petroleum Institute's Recommended Practice for Operation and Maintenance of Offshore Cranes, API RP 2D (as incorporated by reference in §250.198).
- (b) All cranes installed on fixed platforms must be equipped with a functional anti-two block device.
- (c) If a fixed platform is installed after March 17, 2003, all cranes on the platform must meet the requirements of American Petroleum Institute Specification for Offshore Pedestal Mounted